

Cleaning Procedure for IDAS Filters

ICAS Enterprises

1. When stain(s) are dried dusts, just use air blow to remove them.
2. When stain(s) cannot be removed with air blow:
First, air blow to make sure to dust off any other gritty particles than unremovable stains, and then use a lens cleaning paper impregnated with lens cleaning liquid, and slowly and gently wipe them out.
Note: Lens cleaning liquid must NOT be acid or alkaline but must be [neutral](#).
3. When to use a silicone-impregnated cloth:
Air blow dust(s) (especially gritty particles), and gently wipe them out with the cleaning cloth.