

# Installation Manual

## IDASmio **M** Filters

The IDASmio M Filter can be attached to and detached from:  
EOS Digital APS-C Mirrorless and EOS M series cameras


**\*This filter can NOT be used with any EF-M lens of which rear part is any farther extruded than the electrical contacts.**

Note on the usage of the M Filter:

As the M Filter is a thin-layered interference filter, the optical properties of the filter changes depending on the angles of the incoming light rays. Use within a converging lens system having the F number of F1.4 or greater.

Installation to the camera:

1) Install the M filter while placing the camera so the mount becomes upward. Insert the M filter into the dented portion of the body mount.



2) Align the aperture of the M filter with the rectangular aperture of the body mount. You can rotate the M filter even after the insertion.



3) Now you can mount an EF-M lens or an EF-EF-M mount adapter.

Useful Hint:

You can install the IDASmio **CA** filter to the EF-EF-M mount.